

1050 Turbine Parts List

January 1, 2013

Diagram #	Part #	Description	Quantity
1	A4814	Front plate	1
2	A4029	Switch & Plate	1
3	A4028	Power cord 8'	1
4	TC1038	IEC 320 male computer plug	1
5	A4318	Green grounding screw	1
6	A4318	6-32 x 1/2" phill pan m/s plated	11
7	A4307	6-32 Hex M/S nuts, plated	9
8	A4179	Wire terminal	2
9	A4991	6" piece of Black wire, 14 AWG	1
10	A4178	Ground terminal - Large Eye	1
11	A4180	Ground terminal - Small Eye Connector	1
12	A4999	6" piece of grounding wire, 14 AWG	2
13	A4350	1/4" x 20 x 2 3/4" full thread hex	4
14	A4308	1/4" x 20 Hex Nuts	19
15	A4349	1/4" x 20 length 7/8 hex	3
16	A4176	Spliced rubber gasket	1
17	A4371	Bolt 1/4 x 20 x 3 1/4 half thread hex	3
18	A4858-EM	5-stage, 5.7" tangential motor	1
19	A4756	Male Turbine adapter	1
20	A7537	Female air bleed Adapter	1
21	A4815	Housing/cover	1
22	A4177	Hose clamp size 28-1/2"	2
23	A4222	Rubber hose, turbine exhaust	1
24	A4806	Base	1
25	A4300	1/4" SAE Flat Washer, plated	15
26	A4320	1/4" x 20 x 1/2" Hex Bolt, plated	12
27	A4817SS	Case top	1
28	A4139	Carrying handle	1
29	A4345	5/16" handle cap	2
30	A4169	Filter element, 6 x 2 round	2
31	A4190	Pre-filter 3/8" x 2 1/4" x 19"	2
32	A4181	Round filter plate	2
33	A4310	1/4" x 20 cap nut plated	4
34	A2070B	Female Quick Connector	3
42	A2118	1/4" NPT X 1/4" Male hose barb.	1
43	A4857	Vent Manifold	1
44	A5415	Bleed hose 12"	1
45	A5414	Hose clamp	1
46	A4367	Handi-Hold mounting bolt	1
47	A4302	Handi-Hold mounting washer	1
48	A5416	Handi-Hold mounting block	1
49	A4315	#8 X 3/8" HWH sheet metal screw	2
Hose Fittings			
35	ST2163	5/8" black alloy hose adapter (male)	1
36	A2069	S.S. hose clip 15/16" O.D.	2
37	A2168	S.S. hose clip 7/8" O.D.	2
38	A2155	5/8" brass air hose joiner	1
39	A2157	4 feet of flex hose, per foot	4
40	A2111B	5/8" black alloy air hose adapter (male)	1
41	A2167	20 feet of air hose, per foot	20