



**ApolloSpray A5021
Touch-Up Spray Gun
Diagram & Parts List
760-727-8300**

Diagram #	Part #	Description
1	A5200	Air cap ring
2	A5201	Air cap # 1
2	A5297	Air cap # 2
3	A5203	Air distributor plate (stainless)
4	A5204	Air distributor spring (stainless)
5	A5212	Spray Gun Body
6	A5206	Fluid nozzle/jet (stainless) .75MM
6	A5207	Fluid nozzle/jet (stainless) 1.00MM
6	A5208	Fluid nozzle/jet (stainless) 1.50MM
6	A5208-2	Fluid nozzle/jet (stainless) 2.00MM
6	A5209	Fluid nozzle/jet (stainless) 2.50MM
7	A5210	Fluid nozzle gasket
8	A5211	Air feed connector
9	A5213	Trigger bushing
10	A5214	Trigger pivot screw (stainless)
11	A5215	Trigger screw washer
12	A5202	Air blanking plug
13	A5218	Needle (stainless) .75MM
13	A5219	Needle (stainless) 1.00MM
13	A5220	Needle (stainless) 1.50MM
13	A5220-2	Needle (stainless) 2.00MM
13	A5221	Needle (stainless) 2.50MM
14	A5222	Needle spring (stainless)
15	A5223	Flow screw insert
16	A5224	Material flow adjusting screw
17	A5225	Gun casting (handle)
18	A5226L	Handle tube
19	A5227	Air hose quick release coupler (male)
20	A5228	Gland seal
21	A5229	Gland nut (stainless)
22	A5230	Trigger (stainless)
23	A5404	Lid assembly
24	A5402	Gasket (White poly)
25	A5232	Air feed tube and non-return valve
26	A5403	Material pick-up tube
27	A5401	8-oz. plastic cup
28	A5323	Air Stem
29	A5252	Fluid connector, 1/4" (stainless)
	A5400	Storage lid
	A5405	Pack of (4) 8-oz. cups with lids